



Installation VRK (old code VRS), VRRK Rules


1. Supply / Exhaust VRK - the bend distance




2. Supply / Exhaust VRRK - the bend distance




1. Supply / Exhaust VRK - the bend distance



2. Supply / Exhaust VRRK - the bend distance



Adjustment positioning



Siedziba Firmy / Head Office:

LOXIMIDE Sp. z o.o., ul. Warszawska 164, 05-082 Latchorzew/Warszawa, Polska, tel.: +48 22 292 08 22, fax: +48 22 292 08 23, www.loximide.pl, office@loximide.pl, NIP 835 153 96 22, REGON100065522,